Use If/When: Continuous loop shades with dust cover or insert slat will not raise.

Tools Needed: Screwdriver

Orange sticker is removable

1. Continuous loop must be under tension to unlock, however it should not be stretched too tight.

2. Pull down and hold to mount tensioner using screw for inside mount or bracket and screw for outside mount.

Inside Mount

Outside Mount